

50TCQD Single Package Rooftop Heat Pump with Puron® (R-410A) Refrigerant Sizes 17 & 24



Installation Instructions

NOTE: Read the entire instruction manual before starting the installation


TABLE OF CONTENTS

SAFETY CONSIDERATIONS	1
INSTALLATION	6
Step 1 - Plan for Unit Location	6
Step 2 - Plan for Sequence of Unit Installation	7
Step 3 - Inspect Unit	7
Step 4 - Provide Unit Support	7
Step 5 - Field Fabricate Ductwork	10
Step 6 - Rig and Place Unit	10
Step 7 - Duct Connection	11
Step 8 - Install Outside Air Hood	12
Step 9 - Install External Condensate Trap and Line ..	13
Step 10 - Make Electrical Connections	13
Step 11 - Adjust Factory-Installed Options	42
Step 12 - Install Accessories	42
APPENDIX — TYPICAL WIRING DIAGRAMS ...	43

SAFETY CONSIDERATIONS

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock or other conditions which may cause personal injury or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses and work gloves. Use quenching cloths for brazing operations and have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions attached to the unit. Consult local building codes and appropriate national electrical codes (in USA, ANSI/NFPA70, National Electrical Code (NEC); in Canada, CSA C22.1) for special requirements.

It is important to recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, CAUTION, and NOTE. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices, which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

⚠ WARNING**ELECTRICAL SHOCK HAZARD**

Failure to follow this warning could cause personal injury or death.

Before performing service or maintenance operations on unit, always turn off main power switch to unit and install lockout tag. Unit may have more than one power switch.

⚠ WARNING**UNIT OPERATION AND SAFETY HAZARD**

Failure to follow this warning could cause personal injury, death and/or equipment damage.

Puron® (R-410A) refrigerant systems operate at higher pressures than standard R-22 systems. Do not use R-22 service equipment or components on Puron refrigerant equipment.

⚠ WARNING**PERSONAL INJURY AND ENVIRONMENTAL HAZARD**

Failure to follow this warning could cause personal injury or death.

Relieve pressure and recover all refrigerant before system repair or final unit disposal.



Wear safety glasses and gloves when handling refrigerants. Keep torches and other ignition sources away from refrigerants and oils.

⚠ CAUTION**CUT HAZARD**

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing air conditioning equipment.

NOTES:

1. DIMENSIONS ARE IN INCHES, DIMENSIONS IN () ARE IN MILLIMETERS.
2.  CENTER OF GRAVITY
3.  DIRECTION OF AIR FLOW




Fig. 1 - Unit Dimensional Drawing – Size 17 Units

C10135

50TCQD

UNIT	MAX UNIT WEIGHT		CORNER WEIGHT (A)		CORNER WEIGHT (B)		CORNER WEIGHT (C)		CORNER WEIGHT (D)		C.G.		
	LBS.	KG.	LBS.	KG.	LBS.	KG.	LBS.	KG.	LBS.	KG.	X	Y	Z
50TCQ-17	2156	980	581	264	442	201	489	222	643	292	45 1/4 [1149]	55 1/2 [1405]	16 1/2 [419]




Fig. 1 - Unit Dimensional Drawing – Size 17 Unit (cont.)

C10136




Fig. 2 - Unit Dimensional Drawing – Size 24 Unit

C10137




Fig. 2 - Unit Dimensional Drawing – Size 24 Unit (cont.)

C10138

INSTALLATION

Jobsite Survey

Complete the following checks before installation.

- 1. Consult local building codes and the NEC (National Electrical Code) ANSI/NFPA 70 for special installation requirements.
- 2. Determine unit location (from project plans) or select unit location.
- 3. Check for possible overhead obstructions which may interfere with unit lifting or rigging.

Step 1 — Plan for Unit Location

Select a location for the unit and its support system (curb or other) that provides for the minimum clearances required for safety. This includes the clearance to combustible surfaces, unit performance and service access below, around and above unit as specified in unit drawings. See Fig. 3.

NOTE: Consider also the effect of adjacent units.

Unit may be installed directly on wood flooring or on Class A, B, or C roof-covering material when roof curb is used.

Do not install unit in an indoor location. Do not locate air inlets near exhaust vents or other sources of contaminated air.




Fig. 3 - Service Clearance Dimensional Drawing

C09121

Although unit is weatherproof, avoid locations that permit water from higher level runoff and overhangs to fall onto the unit.

Select a unit mounting system that provides adequate height to allow installation of condensate trap per requirements. Refer to Step 9 — Install External Condensate Trap and Line – for required trap dimensions.

Roof mount —

Check building codes for weight distribution requirements. Unit operating weight is shown in Table 1.

Table 1 – Operating Weights

50TCQD	UNITS LB (KG)	UNITS LB (KG)
Component	17	24
Base Unit	2035 (923)	2200 (998)
Economizer	245 (111)	245 (111)
Powered Outlet	32 (15)	32 (15)
Curb		
14-in/356 mm	243 (111)	273 (124)
24-in/610 mm	315 (143)	350 (159)

Step 2 — Plan for Sequence of Unit Installation

The support method used for this unit will dictate different sequences for the steps of unit installation. For example, on curb-mounted units, some accessories must be installed on the unit before the unit is placed on the curb. Review the following for recommended sequences for installation steps.

Curb-mounted installation —

- Install curb
- Install field-fabricated ductwork inside curb
- Install thru-base service connection fittings (affects curb and unit)
- Rig and place unit
- Remove top skid
- Install condensate line trap and piping
- Make electrical connections
- Install other accessories

Pad-mounted installation —

- Prepare pad and unit supports
- Rig and place unit
- Remove duct covers and top skid
- Install field-fabricated ductwork at unit duct openings
- Install condensate line trap and piping
- Make electrical connections
- Install other accessories

Frame-mounted installation —

- Frame-mounted applications generally follow the sequence for a curb installation. Adapt as required to suit specific installation plan.

Step 3 — Inspect unit

Inspect unit for transportation damage. File any claim with transportation agency.

Confirm before installation of unit that voltage, amperage and circuit protection requirements listed on unit data plate agree with power supply provided.

Step 4 — Provide Unit Support

Roof Curb Mount —

Accessory roof curb details and dimensions are shown in Fig. 4 (size 17 and 20 units) and Fig. 5 (size 24 and 28 units). Assemble and install accessory roof curb in accordance with instructions shipped with the curb.

NOTE: The gasketing of the unit to the roof curb is critical for a watertight seal. Install gasket supplied with the roof curb as shown in Fig. 4 and Fig. 5. Improperly applied gasket can also result in air leaks and poor unit performance.

Curb should be level. This is necessary for unit drain to function properly. Unit leveling tolerances are shown in Fig. 6. Refer to Accessory Roof Curb Installation Instructions for additional information as required.

Install insulation, cant strips, roofing felt, and counter flashing as shown. *Ductwork must be attached to curb and not to the unit. Thru-the-base power connection must be installed before the unit is set on the roof curb.*

If electric and control wiring is to be routed through the basepan remove knockouts in basepan located in control box area, see Fig. 7 for location. Attach the service connections to the basepans.

Slab Mount (Horizontal Units Only) —

Provide a level concrete slab that extends a minimum of 6-in. (150 mm) beyond unit cabinet. Install a gravel apron in front of condenser coil air inlet to prevent grass and foliage from obstructing airflow.


NOTE: Horizontal units may be installed on a roof curb if required.

Alternate Unit Support (In Lieu of Curb or Slab Mount) —

A non-combustible sleeper rail can be used in the unit curb support area. If sleeper rails cannot be used, support the long sides of the unit with a minimum of 4 equally spaced 4-in. x 4-in. (102 mm x 102 mm) pads on each side. Locate pads so that they support the rails. Make sure to avoid the fork openings.

UNIT SIZE	"A"	ROOF CURB ACCESSORY
17	1'-2" [356.0] 2'-0" [610.0]	CRRFCURB045A00 CRRFCURB046A00



50TCQD



NOTES:

- 1 ROOF CURB ACCESSORY IS SHIPPED UNASSEMBLED.
- 2 DIMENSIONS IN [] ARE IN MILLIMETERS.
- 3 ROOF CURB GALVANIZED STEEL.
- 4 ATTACH DUCTWORK TO CURB (FLANGES ON DUCT REST ON CURB)
- 5 SERVICE CLEARANCE 4 ft ON EACH SIDE

➔ DIRECTION OF AIR FLOW



MAX CURB LEVELING TOLERANCES









Fig. 4 - Roof Curb Details – Size 17 Units

C10139


UNIT SIZE	"A"	ROOF CURB ACCESSORY
24	1'-2" [356.0] 2'-0" [610.0]	CRRFCURB047A00 CRRFCURB048A00



NOTES:

- 1 ROOF CURB ACCESSORY IS SHIPPED UNASSEMBLED.
- 2 DIMENSIONS IN [] ARE IN MILLIMETERS.
- 3 ROOF CURB GALVANIZED STEEL.
- 4 ATTACH DUCTWORK TO CURB (FLANGES ON DUCT REST ON CURB)
- 5 SERVICE CLEARANCE 4 ft ON EACH SIDE

➔ DIRECTION OF AIR FLOW



MAX CURB LEVELING TOLERANCES







Fig. 5 - Roof Curb Details – Size 24 Units

C10140




Fig. 6 - Unit Leveling Tolerances

C09132




Fig. 7 - Typical Access Panel and Compressor Locations

C09118

Step 5 — Field Fabricate Ductwork

Cabinet return-air static pressure (a negative condition) shall not exceed 0.5 in. wg (87 Pa) with economizer or without economizer.

For vertical ducted applications, secure all ducts to roof curb and building structure. *Do not connect ductwork to unit.*

Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through unconditioned spaces must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes.

For units with accessory electric heaters, minimum clearance is not required around ductwork. One inch (25 mm) clearance to combustible materials must be maintained for the first 48 inches (1220 mm) of ductwork exiting the unit. This applies to horizontal and vertical applications.

Outlet grilles must not lie directly below unit discharge.

NOTE: A 90-degree elbow must be provided in the ductwork to comply with UL (Underwriters Laboratories) code for use with electric heat.

⚠ WARNING

PERSONAL INJURY HAZARD

Failure to follow this warning could cause personal injury.

For vertical supply and return units, tools or parts could drop into ductwork and cause an injury. Install a 90-degree turn in the return ductwork between the unit and the conditioned space. If a 90-degree elbow cannot be installed, then a grille of sufficient strength and density should be installed to prevent objects from falling into the conditioned space. Due to electric heater, supply duct will require 90-degree elbow.

Step 6 — Rig and Place Unit

Keep unit upright and do not drop. Spreader bars are not required if top crating is left on unit. Rollers may be used to move unit across a roof. Level by using unit frame as a reference. See Table 1 (on page 7) and Fig. 8 for additional information.

Lifting holes are provided in base rails as shown in Fig. 8. Refer to rigging instructions on unit.

⚠ CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

All panels must be in place when rigging. Unit is not designed for handling by fork truck.

Before setting the unit onto the curb, recheck gasketing on curb.


Positioning on Curb —

Position unit on roof curb so that the following clearances are maintained: $\frac{1}{4}$ in. (6 mm) clearance between the roof curb and the base rail inside the right and left, $\frac{1}{2}$ in. (12 mm) clearance between the roof curb and the base rail inside the front and back. This will result in the distance between the roof curb and the base rail inside on the condenser end of the unit being approximately equal to Detail A in Figs. 4 and 5.

Do not attempt to slide unit on curb after unit is set. Doing so will result in damage to the roof curb seal.

Although unit is weatherproof, guard against water from higher level runoff and overhangs.

After unit is in position, remove rigging skids and shipping materials.



C09107

UNIT	MAX WEIGHT		DIMENSIONS					
			A		B		C	
	LB	KG	IN	MM	IN	MM	IN	MM
50TCQD17	2070	940	127.8	3249	58.7	1491	52.3	1328
50TCQD24	2358	1071	141.5	3595	58.7	1491	52.3	1328


NOTES:

1. Dimensions in () are in millimeters.
2. Hook rigging shackles through holes in base rail, as shown in detail "A." Holes in base rails are centered around the unit center of gravity. Use wooden top to prevent rigging straps from damaging unit.

Fig. 8 - Rigging Details

Step 7 — Duct Connection

Field-supplied ($\frac{3}{4}$ -inch) flanges should be attached to horizontal duct openings (see Fig. 9) and all ductwork should be secured to the flanges. Insulate and weatherproof all external ductwork, joints, and roof or building openings with counter flashing and mastic in accordance with applicable codes.



C10141


Fig. 9 - Horizontal Duct Opening Dimensions

50TCQD

Step 8 — Install Outside Air Hood

Economizer and Two Position Hood Removal - Factory Option

- The hood is shipped in knock-down form and is located in the indoor air compartment. The hood is strapped to the blower assembly. (See Fig. 10)




C09150

Fig. 10 - Hood Package - Shipping Location

- To gain access to the hood, remove the back blower access panel.
- Locate and cut the strap, being careful to not damage any wiring.
- Carefully lift the hood assembly through the back blower access opening and assemble per the steps outlined in the following procedure.

Two Position Damper and Economizer Hood Installation - Factory Option

- Remove hood top from shipping position. (See Fig. 11)




C09134

Fig. 11 - Hood Top - Shipping Position

See Fig. 12 for identification of the various parts of the hood assembly.


- Install four angles to the upper end panel using the screws provided
- Apply seal strip to mating flanges on the side plates of the hood (see Fig. 12).



C09079

Fig. 12 - Hood Part Identification and Seal Strip Application Areas

- Secure side plates to panel using the screws provided.
- Apply seal strip to mating flange of the hood (see Fig. 12).
- On size 17, 20 and 24 units, remove screws across top cover. Attach hood to side plates. (On these units the hood flange slides behind flange of top cover.)
- On size 17, 20 and 24 units, secure the top flange using the screws removed in step 6. On size 28 units, secure top flange using screws provided in kit.
- Install outdoor air screens by sliding them into the channel formed by the four angles installed in step 2. Make sure that the screens extend across the entire length of the hood.
- Install side filter supports using the screws provided
- Install side drip angles using the screws provided.
- Run a continuous length of seal strip across the hood covering the engagement holes in the lower hood.
- Install top diverter using the screws provided.
- On units with barometric relief, remove screws at bottom of relief damper. **Do not discard damper door.**



C09090

Fig. 13 - Hood Assembly - Completed

Step 9 — Install External Condensate Trap and Line

The unit has one $\frac{3}{4}$ -in. condensate drain connection on the end of the condensate pan (see Fig. 14) See Fig. 1 (or Fig. 2), item “E”, in the view labeled “BACK (HORIZONTAL DISCHARGE)” for the location of the condensate drain connection.





Fig. 14 - Condensate Drain Pan Connection

The piping for the condensate drain and external trap can be completed after the unit is in place. Hand tighten fittings to the drain pan fitting. Provide adequate support for the drain line. Failure to do so can result in damage to the drain pan. See Fig. 15.



NOTE: Trap should be deep enough to offset maximum unit static difference. A 4" (102) trap is recommended

Fig. 15 - Condensate Drain Piping Details

All units must have an external trap for condensate drainage. Install a trap at least 4-in. (102 mm) deep and protect against freeze-up. If drain line is installed downstream from the external trap, pitch the line away from the unit at 1-in. per 10 ft (25 mm in 3 m) of run. Do not use a pipe size smaller than the unit connection ($\frac{3}{4}$ -in.).

Step 10 — Make Electrical Connections

⚠ WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Do not use gas piping as an electrical ground. Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC (National Electrical Code); ANSI/NFPA 70, latest edition (in Canada, Canadian Electrical Code CSA [Canadian Standards Association] C22.1), and local electrical codes.

NOTE: Check all factory and field electrical connections for tightness. Field-supplied wiring shall conform with the limitations of 63°F (33°C) rise.

Field Power Supply —

If equipped with optional Powered Convenience Outlet: The power source leads to the convenience outlet's transformer primary are not factory connected. Installer must connect these leads according to required operation of the convenience outlet. If an always-energized convenience outlet operation is desired, connect the source leads to the line side of the unit-mounted disconnect. (Check with local codes to ensure this method is acceptable in your area.) If a de-energize via unit disconnect switch operation of the convenience outlet is desired, connect the source leads to the load side of the unit disconnect. On a unit without a unit-mounted disconnect, connect the source leads to the terminal block with unit field power leads.

Field power wires are connected to the unit at line-side pressure lugs on the terminal block (see wiring diagram label for control box component arrangement) or at factory-installed option non-fused disconnect switch. Use copper conductors only.

NOTE: Make field power connections directly to line connection pressure lugs only.


All units except 208/230-v units are factory wired for the voltage shown on the nameplate. *If the 208/230-v unit is to be connected to a 208-v power supply, the control transformer must be rewired by moving the black wire with the $\frac{1}{4}$ -in. female spade connector from the 230-v connection and moving it to the 208-v $\frac{1}{4}$ -in. male terminal on the primary side of the transformer.* Refer to unit label diagram for additional information.

⚠ WARNING

FIRE HAZARD

Failure to follow this warning could result in intermittent operation or performance satisfaction.

Do not connect aluminum wire between disconnect switch and air conditioning unit. Use only copper wire. (See Fig. 16.)



A93033

Fig. 16 - Disconnect Switch and Unit

Units Without Factory-Installed Disconnect —

When installing units, provide a disconnect switch per NEC (National Electrical Code) of adequate size. Disconnect sizing data is provided on the unit informative plate. Locate on unit cabinet or within sight of the unit per national or local codes. Do not cover unit informative plate if mounting the disconnect on the unit cabinet.

Units with Factory-Installed Disconnect —

The factory-installed option disconnect switch is located in the main control box. The manual switch handle is accessible on the corner post adjacent to the control box access panel.


All units -

All field wiring must comply with NEC and all local codes. Size wire based on MCA (Minimum Circuit Amps) on the unit informative plate. See Fig. 17 for power wiring connections to the unit power terminal block and equipment ground.


Provide a ground-fault and short-circuit over-current protection device (fuse or breaker) per NEC Article 440 (or local codes). Refer to unit informative data plate for MOCP (Maximum Over-current Protection) device size.

All field wiring must comply with the NEC and local requirements.

Units Without Disconnect Option



Units With Disconnect Option



C09057

Fig. 17 - Power Wiring Connections

Convenience Outlets —


⚠ WARNING

ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death.

Units with convenience outlet circuits may use multiple disconnects. Check convenience outlet for power status before opening unit for service. Locate its disconnect switch, if appropriate, and open it. Tag-out this switch, if necessary.

Two types of convenience outlets are offered on 48TC*D models: Non-powered and unit-powered. Both types provide a 125-volt GFCI (ground-fault circuit-interrupter) duplex receptacle rated at 15-A behind a hinged access cover, located on the corner panel of the unit. See Fig. 18.



C09119

Fig. 18 - Convenience Outlet Location

Installing Weatherproof Cover –

A weatherproof while-in-use cover for the factory-installed convenience outlets is now required by UL standards. This cover cannot be factory-mounted due its depth; it must be installed at unit installation. For shipment, the convenience outlet is covered with a blank cover plate.


The weatherproof cover kit is shipped in the unit's control box. The kit includes the hinged cover, a backing plate and gasket.

DISCONNECT ALL POWER TO UNIT AND CONVENIENCE OUTLET.

Remove the blank cover plate at the convenience outlet; discard the blank cover.

Loosen the two screws at the GFCI duplex outlet, until approximately 1/2-in (13 mm) under screw heads are exposed. Press the gasket over the screw heads. Slip the backing plate over the screw heads at the keyhole slots and align with the gasket; tighten the two screws until snug (do not over-tighten).

Mount the weatherproof cover to the backing plate as shown in Fig. 19. Remove two slot fillers in the bottom of the cover to permit service tool cords to exit the cover. Check for full closing and latching.




C09022

Fig. 19 - Weatherproof Cover Installation

Non-powered type: This type requires the field installation of a general-purpose 125-volt 15-A circuit powered from a source elsewhere in the building. Observe national and local codes when selecting wire size, fuse or breaker requirements and disconnect switch size and location. Route 125-v power supply conductors into the bottom of the utility box containing the duplex receptacle.

Unit-powered type: A unit-mounted transformer is factory-installed to stepdown the main power supply voltage to the unit to 115-v at the duplex receptacle. This option also includes a manual switch with fuse, located in a utility box and mounted on a bracket behind the convenience outlet; access is through the unit's control box access panel. See Fig. 18.

The primary leads to the convenience outlet transformer are not factory-connected. If local codes permit, the transformer primary leads can be connected at the line-side terminals on the unit-mounted non-fused disconnect switch; this will provide service power to the unit when the unit disconnect switch is open. See Fig. 20.



C09250

UNIT VOLTAGE	CONNECT AS	PRIMARY CONNECTIONS	TRANSFORMER TERMINALS
208, 230	240	L1: RED + YEL L2: BLU + GRA	H1 + H3 H2 + H4
460	480	L1: RED Splice BLU + YEL L2: GRA	H1 H2 + H3 H4
575	600	L1: RED L2: GRA	H1 H2

Fig. 20 - Powered Convenience Outlet Wiring

Duty Cycle: the unit-powered convenience outlet has a duty cycle limitation. The transformer is intended to provide power on an intermittent basis for service tools, lamps, etc; it is not intended to provide 15-amper loading for continuous duty loads (such as electric heaters for overnight use). Observe a 50% limit on circuit loading above 8-amper (i.e., limit loads exceeding 8-amper to 30 minutes of operation every hour).

Test the GFCI receptacle by pressing the TEST button on the face of the receptacle to trip and open the receptacle. Check for proper grounding wires and power line phasing

if the GFCI receptacle does not trip as required. Press the RESET button to clear the tripped condition.

Fuse on power type: The factory fuse is a Bussman FNQ-7 dual element time delay fuse.

Using unit-mounted convenience outlets: Units with unit-mounted convenience outlet circuits will often require that two disconnects be opened to de-energize all power to the unit. Treat all units as electrically energized until the convenience outlet power is also checked and de-energization is confirmed. Observe National Electrical Code Article 210, Branch Circuits, for use of convenience outlets.

Factory-Option Thru-Base Connections —

All units are equipped with the ability to bring utilities through the base.

The electrical entrance is located in the control box area and can be accessed through the control box access panel. An embossed area is provided with three knock outs. High voltage is brought through the multi knock out by removing the appropriate size for the size of the fitting required. A $\frac{7}{8}$ -in. knock out is provided for low voltage. An additional $\frac{7}{8}$ -in. knock out is provided for a 115 volt line which is used when the unit is equipped with the non-powered convenience outlet option.

All required fittings are field supplied. Install fittings when access to both top and bottom of the base pan is available.

Units without Thru-Base Connections —

1. Install conduit, liquid tight, between disconnect and control box.
2. Pull correctly rated high voltage wires through the conduit.
3. Install power lines to terminal connections as shown in Fig. 17.

All Units —

Voltage to compressor terminals during operation must be within voltage range indicated on unit nameplate. On 3-phase units, voltages between phases must be balanced within 2% and the current within 10%. Use the following formula to determine the percent of voltage imbalance.

$$\% \text{ Voltage Imbalance} = 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

C09103

Operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components. Such operation would invalidate any applicable Carrier warranty.

Field Control Wiring —

The 50TCQD unit requires an external temperature control device. This device can be a thermostat (field-supplied) or a PremierLink controller (available as factory-installed option or as field-installed accessory, for use on a Carrier Comfort Network or as a stand alone


control) or the RTU-MP Controller for Building Management Systems using non-CCN protocols (RTU-MP is available as a factory-installed option only).

Thermostat —

Install a Carrier-approved accessory thermostat according to installation instructions included with the accessory. For complete economizer function, select a two-stage cooling thermostat. Locate the thermostat accessory on a solid wall in the conditioned space to sense average temperature in accordance with the thermostat installation instructions.

If the thermostat contains a logic circuit requiring 24-v power, use a thermostat cable or equivalent single leads of different colors with minimum of seven leads. If the thermostat does not require a 24-v source (no "C" connection required), use a thermostat cable or equivalent with minimum of six leads. Check the thermostat installation instructions for additional features which might require additional conductors in the cable.

For wire runs up to 50 ft. (15 m), use no. 18 AWG (American Wire Gage) insulated wire (35°C minimum). For 50 to 75 ft. (15 to 23 m), use no. 16 AWG insulated wire (35°C minimum). For over 75 ft. (23 m), use no. 14 AWG insulated wire (35°C minimum). All wire sizes larger than no. 18 AWG cannot be directly connected to the thermostat and will require a junction box and splice at the thermostat.



Note 1: Typical multi-function marking. Follow manufacturer's configuration instructions to select Y2.

Note 2: Y2 to Y2 connection required on single-stage cooling units when integrated economizer function is desired.

Note 3: W2 connection not required on units with single-stage heating.

--- Field Wiring

C09257

Fig. 21 - Typical Low-Voltage Control Connections

Unit without thru-base connection —

Correctly rated low voltage wire can be routed through the rubber grommet located on the corner post adjacent to the control box access panel. Route wire through the grommet

and then route the wire behind the corner post utilizing the factory provided wire ties secured to the control box. This will insure separation of the field low voltage wire and the high voltage circuit. Route the low voltage wire to the central terminal board. See Fig. 22.

NOTE: If utilizing the through the base connections, route the low voltage wire through the wire ties to the central terminal board.




Fig. 22 - Field Control Wiring Raceway

Heat Anticipator Settings —


Set heat anticipator settings at 0.14 amp for the first stage and 0.14 amp for second-stage heating, when available.

Electric Heaters

50TCQD units may be equipped with field-installed accessory electric heaters. The heaters are modular in design, with heater frames holding open coil resistance wires strung through ceramic insulators, line-break limit switches and a control contactor.

Heater modules are installed in the compartment below the indoor blower access panel. Access is through the electric heat access panel. Heater modules slide into the compartment on tracks along the bottom of the heater opening. See Fig. 23, Fig. 24 and Fig. 25. Refer to the Electric Heater Kit Installation Instructions for complete details.


Not all available heater modules may be used in every unit. Use only those heater modules that are ETL listed for use in a specific size unit. Refer to the label on the unit cabinet for the list of approved heaters.



C09118


Fig. 23 - Typical Access Panel Location

Unit heaters are marked with Heater Model Numbers. But heaters are ordered as and shipped in cartons marked with a corresponding heater Sales Package part number. See Table 2 for correlation between heater Model Number and Sales Package part number.



C09141

Fig. 24 - Typical Component Location



C09142

**Fig. 25 - Electric Heater Compartment
(Cover Removed)**

Low-Voltage Control Connections —

Locate the plug assembly in the electric heater section of the main unit. Connect the plug with the mating low voltage plug located on the heater.

50TCQD

Table 2 – Heater Model Number

Bare Heater Model Number	C	R	H	E	A	T	E	R	2	7	9	A	0	0
Heater Sales Package PNO Includes: Bare Heater Carton and packing materials Installation sheet	C	R	H	E	A	T	E	R	2	7	9	A	0	0

50TCQD




Fig. 26 - Accessory Electric Heater Control Connections

C09149

PremierLink™ (Factory-Option) —




Fig. 27 - PremierLink Controller

C08199

The PremierLink controller (see Fig. 27) is compatible with Carrier Comfort Network® (CCN) devices. This control is designed to allow users the access and ability to change factory-defined settings, thus expanding the function of the standard unit control board. CCN service access tools include System Pilot (TM), Touch Pilot (TM) and Service Tool. (Standard tier display tools Navigator™ and Scrolling Marquee are not suitable for use with latest PremierLink controller (Version 2.x).)

The PremierLink control is factory-mounted in the 50TCQD unit's main control box to the right of the Control Terminal Board (CTB). Factory wiring is completed through harnesses connected to the CTB thermostat. Field connections are made at a 16-pole terminal block (TB1) located on the bottom shelf of the unit control box in front of the PremierLink controller. The factory-installed PremierLink control includes the supply-air temperature (SAT) sensor. The outdoor air temperature (OAT) sensor is included in the FIOP/accessory EconoMi\$er™ 2 package.

The PremierLink controller requires the use of a Carrier electronic thermostat or a CCN connection for time broadcast to initiate its internal timeclock. This is necessary for broadcast of time of day functions (occupied/unoccupied).

NOTE: PremierLink controller is shipped in Sensor mode. To be used with a thermostat, the PremierLink controller must be configured to Thermostat mode. Refer to PremierLink Configuration instructions for Operating Mode.

Supply Air Temperature (SAT) Sensor — On FIOP-equipped 50TCQD unit, the unit is supplied with a supply-air temperature (SAT) sensor (33ZCSENSAT). This sensor is a tubular probe type, approx 6-inches (12.7 mm) in length. It is a nominal 10-k ohm thermistor.

The SAT is factory-wired. The SAT probe is mounted in the fan deck (see Fig. 28). It can be removed or remounted per local codes.. Drill or punch a 1/2-in. hole in the flange or duct. Use two field-supplied, self-drilling screws to secure the sensor probe in a horizontal orientation. Insure that the sensor wires do not contact the hot surface of the electric heaters.




Fig. 28 - Mounting Location for Supply Air Temperature (SAT) Sensor on 50TCQD Units

C09059

NOTE: Refer to Form 33CS-58SI for complete PremierLink configuration, operating sequences and troubleshooting information. Have a copy of this manual available at unit start-up.

NOTE: The sensor must be mounted in the discharge airstream downstream of the cooling coil and any heating devices. Be sure the probe tip does not come in contact with any of the unit's heater surfaces.

50TCQD




Fig. 29 - PremierLink Wiring Schematic

Outdoor Air Temperature (OAT) Sensor — The OAT is factory-mounted in the EconoMi\$er2 (FIOP or accessory). It is a nominal 10k ohm thermistor attached to an eyelet mounting ring.

EconoMi\$er2 — The PremierLink control is used with EconoMi\$er2 (option or accessory) for outdoor air management. The damper position is controlled directly by the PremierLink control; EconoMi\$er2 has no internal logic device.

Outdoor air management functions can be enhanced with field-installation of these accessory control devices:

- Enthalpy control (outdoor air or differential sensors)
- Space CO₂ sensor
- Outdoor air CO₂ sensor


Refer to Table 3 for accessory part numbers.

Field connections — Field connections for accessory sensor and input devices are made at the 16-pole terminal block (TB1) located on the control box top in front of the PremierLink control (See Fig. 29). Some input devices also require a 24-vac signal source; connect at CTB terminal R at “THERMOSTAT” connection strip for this signal source. See connections figures on following pages for field connection locations (and for continued connections at the PremierLink board inputs).

Table 4 provides a summary of field connections for units equipped with Space Sensor. Table 5 provides a summary of field connections for units equipped with Space Thermostat.

Space Sensors - The PremierLink controller is factory-shipped configured for Space Sensor Mode. A Carrier T-55 or T-56 space sensor must be used. T-55 space temperature sensor provides a signal of space


temperature to the PremierLink control. T-56 provides same space temperature signal plus it allows for adjustment of space temperature setpoints from the face of the sensor by the occupants.



C08201

Fig. 30 - T-55 Space Temperature Sensor Wiring

Connect T-55 - See Fig. 30 for typical T-55 internal connections. Connect the T-55 SEN terminals to TB1 terminals 1 and 3 (see Fig. 31).



C08212

Fig. 31 - PremierLink T-55 Sensor

Table 3 – PremierLink Sensor Usage

APPLICATION	OUTDOOR AIR TEMPERATURE SENSOR	RETURN AIR TEMPERATURE SENSOR	OUTDOOR AIR ENTHALPY SENSOR	RETURN AIR ENTHALPY SENSOR
Differential Dry Bulb Temperature with PremierLink (PremierLink requires 4–20 mA Actuator)	Included – CRTEMPN001A00	Required – 33ZCT55SPT or equivalent	–	–
Single Enthalpy with PremierLink (PremierLink requires 4–20mA Actuator)	Included – Not Used	–	Requires – 33CSENTHSW	–
Differential Enthalpy with PremierLink (PremierLink requires 4–20mA Actuator)	Included – Not Used	–	Requires – 33CSENTHSW or equivalent	Requires – 33CSENSEN or equivalent

NOTES:

CO₂ Sensors (Optional):

- 33ZCSENC02 – Room sensor (adjustable). Aspirator box is required for duct mounting of the sensor.
- 33ZCASP02 – Aspirator box used for duct-mounted CO₂ room sensor.
- 33ZCT55CO2 – Space temperature and CO₂ room sensor with override.
- 33ZCT56CO2 – Space temperature and CO₂ room sensor with override and setpoint.

Table 4 – Space Sensor Mode

TB1 TERMINAL	FIELD CONNECTION	INPUT SIGNAL
1	T55 – SEN/T56 – SEN	Analog (10k thermistor)
2	RMT OCC	Discrete, 24VAC
3	T55 – SEN/T56 – SEN	Analog (10k thermistor)
4	CMPSAFE	Discrete, 24VAC
5	T56 – SET	Analog (10k thermistor)
6	FSD	Discrete, 24VAC
7	LOOP – PWR	Analog, 24VDC
8	SPS	Discrete, 24VAC
9	IAQ – SEN	Analog, 4 – 20mA
10	FILTER	Discrete, 24VAC
11	IAQ – COM/OAQ – COM/RH – COM	Analog, 4 – 20mA
12	CCN + (RED)	Digital, , 5VDC
13	OAQ – SEN/RH – SEN	Analog, 4 – 20mA
14	CCN Gnd (WHT)	Digital, 5VDC
15	AUX OUT(Power Exhaust)	(Output) Discrete 24VAC
16	CCN – (BLK)	Digital, 5VDC

LEGEND:

T55	– Space Temperature Sensor	FSD	– Fire Shutdown
T56	– Space Temperature Sensor	IAQ	– Indoor Air Quality (CO ₂)
CCN	– Carrier Comfort Network (communication bus)	OAQ	– Outdoor Air Quality (CO ₂)
CMPSAFE	– Compressor Safety	RH	– Relative Humidity
FILTER	– Dirty Filter Switch	SFS	– Supply Fan Status

Table 5 – Thermostat Mode

TB1 TERMINAL	FIELD CONNECTION	INPUT SIGNAL
1	RAT SEN	Analog (10k thermistor)
2	G	Discrete, 24VAC
3	RAT SEN	Analog (10k thermistor)
4	Y1	Discrete, 24VAC
5		
6	Y2	Discrete, 24VAC
7	LOOP – PWR	Analog, 24VDC
8	W1	Discrete, 24VAC
9	IAQ – SEN	Analog, 4 – 20mA
10	W2	Discrete, 24VAC
11	IAQ – COM/OAQ – COM/RH – COM	Analog, 4 – 20mA
12	CCN + (RED)	Digital, 5VDC
13	OAQ – SEN/RH – SEN	Analog, 4 – 20mA
14	CCN Gnd (WHT)	Digital, 5VDC
15	AUX OUT (Power Exhaust)	(Output) Discrete 24VAC
16	CCN – (BLK)	Digital, 5VDC

LEGEND:

CCN	– Carrier Comfort Network (communication bus)	RH	– Relative Humidity
G	– Thermostat Fan	W1	– Thermostat Heat Stage 1
IAQ	– Indoor Air Quality (CO ₂)	W2	– Thermostat Heat Stage 2
OAQ	– Outdoor Air Quality (CO ₂)	Y1	– Thermostat Cool Stage 1
RAT	– Return Air Temperature	Y2	– Thermostat Cool Stage 2

Connect T-56 - See Fig. 32 for T-56 internal connections. Install a jumper between SEN and SET terminals as illustrated. Connect T-56 terminals to TB1 terminals 1, 3 and 5 (see Fig. 33).




Fig. 32 - T-56 Internal Connections

C08202




Fig. 33 - PremierLink T-56 Sensor

C08213

Connect Thermostat — A 7-wire thermostat connection requires a 24-v power source and a common connection. Use the R and C terminals on the CTB's THERMOSTAT connection strip for these. Connect the thermostat's Y1, Y2, W1, W2 and G terminals to PremierLink TB1 as shown in Fig. 34.

If the 50TCQD unit is equipped with factory-installed smoke detector(s), disconnect the factory BLU lead at TB1-6 (Y2) before connecting the thermostat. Identify the BLU lead originating at CTB-DDC-1; disconnect at TB1-6 and tape off. Confirm that the second BLU lead at TB1-6 remains connected to PremierLink J4-8.




Fig. 34 - Space Thermostat Connections

C08119

If the 50TCQD unit has an economizer system and free-cooling operation is required, a sensor representing Return Air Temperature must also be connected (field-supplied and installed). This sensor may be a T-55 Space Sensor (see Fig. 31) installed in the space or in the return duct, or it may be sensor PNO 33ZCSENSAT, installed in the return duct. Connect this sensor to TB1-1 and TB1-3 per Fig. 31.

Configure the unit for Thermostat Mode — Connect to the CCN bus using a CCN service tool and navigate to PremierLink Configuration screen for Operating Mode. Default setting is Sensor Mode (value 1). Change the value to 0 to reconfigure the controller for Thermostat Mode.

When the PremierLink is configured for Thermostat Mode, these functions are not available: Fire Shutdown (FSD), Remote Occupied (RMT OCC), Compressor Safety (CMPSAFE), Supply Fan Status (SFS), and Filter Pressure Switch (FILTER).


50TCQD

Economizer controls —

Outdoor Air Enthalpy Control (PNO 33CSENTHSW) -

The enthalpy control (33CSENTHSW) is available as a field-installed accessory to be used with the EconoMi\$er2 damper system. The outdoor air enthalpy sensor is part of the enthalpy control. (The separate field-installed accessory return air enthalpy sensor (33CSENTSEN) is required for differential enthalpy control. See Fig. 35.)

Locate the enthalpy control in the economizer next to the Actuator Motor. Locate two GRA leads in the factory harness and connect the gray lead labeled “ESL” to the terminal labeled “LOW”. See Fig. 35. Connect the enthalpy control power input terminals to economizer actuator power leads RED (connect to 24V) and BLK (connect to GND).




C09026

Fig. 35 - Enthalpy Switch (33CSENTHSW) Connections

The outdoor enthalpy changeover setpoint is set at the enthalpy controller.

Differential Enthalpy Control — Differential enthalpy control is provided by sensing and comparing the outside air and return air enthalpy conditions. Install the outdoor air enthalpy control as described above. Add and install a return air enthalpy sensor.



C09027


Fig. 36 - Outside and Return Air Enthalpy Sensor Wiring

To wire the return air enthalpy sensor, perform the following:

1. Use a 2-conductor, 18 or 20 AWG, twisted pair cable to connect the return air enthalpy sensor to the enthalpy controller.
2. Connect the field-supplied RED wire to (+) spade connector on the return air enthalpy sensor and the (+) terminal on the enthalpy controller. Connect the BLK wire to (-) spade connector on the return air enthalpy sensor and the (-) terminal on the enthalpy controller.

Indoor Air Quality (CO₂ sensor) — The indoor air quality sensor accessory monitors space carbon dioxide (CO₂) levels. This information is used to monitor IAQ levels. Several types of sensors are available, for wall mounting in the space or in return duct, with and without LCD display, and in combination with space temperature sensors. Sensors use infrared technology to measure the levels of CO₂ present in the space air.

The CO₂ sensors are all factory set for a range of 0 to 2000 ppm and a linear mA output of 4 to 20. Refer to the instructions supplied with the CO₂ sensor for electrical requirements and terminal locations. See Fig. 37 for typical CO₂ sensor wiring schematic.



C08635

Fig. 37 - Indoor/Outdoor Air Quality (CO₂) Sensor (33ZCSENC02) - Typical Wiring Diagram

To accurately monitor the quality of the air in the conditioned air space, locate the sensor near a return-air grille (if present) so it senses the concentration of CO₂ leaving the space. The sensor should be mounted in a location to avoid direct breath contact.

Do not mount the IAQ sensor in drafty areas such as near supply ducts, open windows, fans, or over heat sources. Allow at least 3 ft (0.9 m) between the sensor and any corner. Avoid mounting the sensor where it is influenced by the supply air; the sensor gives inaccurate readings if

the supply air is blown directly onto the sensor or if the supply air does not have a chance to mix with the room air before it is drawn into the return airstream.

Wiring the Indoor Air Quality Sensor —

For each sensor, use two 2-conductor 18 AWG (American Wire Gauge) twisted-pair cables (unshielded) to connect the separate isolated 24 vac power source to the sensor and to connect the sensor to the control board terminals.

To connect the sensor to the control, identify the positive (4 to 20 mA) and ground (SIG COM) terminals on the sensor. See Fig. 37. Connect the 4-20 mA terminal to terminal TB1-9 and connect the SIG COM terminal to terminal TB1-11. See Fig. 38.




Fig. 38 - Indoor CO₂ Sensor (33ZCSENCO2) Connections

Refer to Form 33CS-58SI, PremierLink Installation, Start-up, and Configuration Instructions, for detailed configuration information.

Outdoor Air Quality Sensor (PNO 33ZCSENCO2 plus weatherproof enclosure) — The outdoor air CO₂ sensor is designed to monitor carbon dioxide (CO₂) levels in the outside ventilation air and interface with the ventilation damper in an HVAC system. The OAQ sensor is packaged with an outdoor cover. See Fig. 39. The outdoor air CO₂ sensor must be located in the economizer outside air hood.




Fig. 39 - Outdoor Air Quality Sensor Cover

Wiring the Outdoor Air CO₂ Sensor — A dedicated power supply is required for this sensor. A two-wire cable is required to wire the dedicated power supply for the sensor.

The two wires should be connected to the power supply and terminals 1 and 2.

To connect the sensor to the control, identify the positive (4 to 20 mA) and ground (SIG COM) terminals on the OAQ sensor. See Fig. 37. Connect the 4 to 20 mA terminal to the TB1-13 terminal of the 50TCQD . Connect the SIG COM terminal to the TB1-11 terminal of the 50TCQD. See Fig. 40.




Fig. 40 - Outdoor CO₂ Sensor Connections

Smoke Detector/Fire Shutdown (FSD) — This function is available only when PremierLink is configured for (Space) Sensor Mode. The unit is factory-wired for PremierLink FSD operation when PremierLink is factory-installed.

On 50TCQD units equipped with factory-installed Smoke Detector(s), the smoke detector controller implements the unit shutdown through its NC contact set connected to the unit's CTB input. The FSD function is initiated via the smoke detector's Alarm NO contact set. The PremierLink communicates the smoke detector's tripped status to the CCN building control. See Fig. 29, the PremierLink wiring schematic.

Filter Status Switch — This function is available only when PremierLink is configured for (Space) Sensor Mode.

PremierLink control can monitor return filter status in two ways: By monitoring a field-supplied/installed filter pressure switch or via supply fan runtime hours.

Using switch input: Install the dirty filter pressure switch according to switch manufacturer's instructions, to measure pressure drop across the unit's return filters. Connect one side of the switch's NO contact set to CTB's THERMOSTAT-R terminal. Connect the other side of the NO contact set to TB1-10. Setpoint for Dirty Filter is set at the switch. See Fig. 41.




Fig. 41 - PremierLink Filter Switch Connection

When the filter switch's NO contact set closes as filter pressure drop increases (indicating dirt-laden filters), the

input signal to PremierLink causes the filter status point to read “DIRTY”.

Using Filter Timer Hours: Refer to Form 33CS-58SI for instructions on using the PremierLink Configuration screens and on unit alarm sequence.

Supply Fan Status Switch — The PremierLink control can monitor supply fan operation through a field-supplied/installed differential pressure switch. This sequence will prevent (or interrupt) operation of unit cooling, heating and economizer functions until the pressure switch contacts are closed indicating proper supply fan operation.

Install the differential pressure switch in the supply fan section according to switch manufacturer’s instructions. Arrange the switch contact to be open on no flow and to close as pressure rises indicating fan operation.

Connect one side of the switch’s NO contact set to CTB’s THERMOSTAT-R terminal. Connect the other side of the NO contact set to TB1-8. Setpoint for Supply Fan Status is set at the switch. See Fig. 42.




Fig. 42 - PremierLink Wiring Fan Pressure Switch Connection

Remote Occupied Switch — The PremierLink control permits a remote timeclock to override the control’s on-board occupancy schedule and place the unit into Occupied mode. This function may also provide a “Door Switch” time delay function that will terminate cooling and heating functions after a 2-20 minute delay.

Connect one side of the NO contact set on the timeclock to CTB’s THERMOSTAT-R terminal. Connect the other side of the timeclock contact to the unit’s TB1-2 terminal.




Fig. 43 - PremierLink Wiring Remote Occupied

Refer to Form 33CS-58SI for additional information on configuring the PremierLink control for Door Switch timer function.

Power Exhaust (output) - Connect the accessory Power Exhaust contactor coils(s) per Fig. 44.

Space Relative Humidity Sensor — The RH sensor is not used with 50TCQD models at this time.




Fig. 44 - PremierLink Power Exhaust Output Connection

CCN Communication Bus — The PremierLink controller connects to the bus in a daisy chain arrangement. Negative pins on each component must be connected to respective negative pins, and likewise, positive pins on each component must be connected to respective positive pins. The controller signal pins must be wired to the signal ground pins. Wiring connections for CCN must be made at the 3-pin plug.

At any baud (9600, 19200, 38400 baud), the number of controllers is limited to 239 devices maximum. Bus length may not exceed 4000 ft, with no more than 60 total devices on any 1000-ft section. Optically isolated RS-485 repeaters are required every 1000 ft.

NOTE: Carrier device default is 9600 band.

COMMUNICATION BUS WIRE SPECIFICATIONS — The CCN Communication Bus wiring is field-supplied and field-installed. It consists of shielded 3-conductor cable with drain (ground) wire. The cable selected must be identical to the CCN Communication Bus wire used for the entire network.

See Table 6 for recommended cable.

Table 6 – Recommended Cables

MANUFACTURER	CABLE PART NO.
Alpha	2413 or 5463
American	A22503
Belden	8772
Columbia	02525

NOTE: Conductors and drain wire must be at least 20 AWG, stranded, and tinned copper. Individual conductors must be insulated with PVC, PVC/nylon, vinyl, Teflon, or polyethylene. An aluminum/polyester 100% foil shield and an outer jacket of PVC, PVC/nylon, chrome vinyl, or Teflon with a minimum operating temperature range of -20°C to 60°C is required. Do not run communication wire in the same conduit as or next to any AC voltage wiring.

The communication bus shields must be tied together at each system element. If the communication bus is entirely within one building, the resulting continuous shield must be connected to ground at only one single point. If the communication bus cable exits from one building and

enters another building, the shields must be connected to the grounds at a lightning suppressor in each building (one point only).

Connecting CCN bus:

NOTE: When connecting the communication bus cable, a color code system for the entire network is recommended to simplify installation and checkout. See Table 7 for the recommended color code.

Table 7 – Color Code Recommendations

SIGNAL TYPE	CCN BUS WIRE COLOR	CCN PLUG PIN NUMBER
+	Red	1
Ground	White	2
–	Black	3

Connect the CCN (+) lead (typically RED) to the unit's TB1-12 terminal. Connect the CCN (ground) lead (typically WHT) to the unit's TB1-14 terminal. Connect the CCN (–) lead (typically BLK) to the unit's TB1-16 terminal. See Fig. 45.




Fig. 45 - PremierLink CCN Bus Connections

RTU-MP control system

The RTU-MP controller, see Fig. 46, provides expanded stand-alone operation of the HVAC system plus connection and control through communication with several Building Automation Systems (BAS) through popular third-party network systems. The available network systems are BACnet MP/TP, Modbus and Johnson J2. Communication with LonWorks is also possible by adding an accessory interface card to the RTU-MP. Selection of the communication protocol and baud rate are made at on-board DIP switches.

The RTU-MP control is factory-mounted in the 50TCQD unit's main control box, to the right of the CTB. See Fig. 47. Factory wiring is completed through harnesses connected to the CTB. Field connections for RTU-MP sensors will be made at the Phoenix connectors on the RTU-MP board. The factory-installed RTU-MP control includes the supply-air temperature (SAT) sensor. The outdoor air temperature (OAT) sensor is included in the FIOP/accessory EconoMi\$er2 package.

Refer to Table 8, RTU-MP Controller Inputs and Outputs for locations of all connections to the RTU-MP board.

50TCQD




Fig. 46 - RTU-MP Multi-Protocol Control Board

C07129




Fig. 47 - 50TCQD Control Box Component Locations

C10181




Fig. 48 - RTU-MP System Control Wiring Diagram

Table 8 – RTU-MP Controller Inputs and Outputs

POINT NAME	BACnet OBJECT NAME	TYPE OF I/O	CONNECTION PIN NUMBERS
INPUTS			
Space Temperature Sensor	sptsens	AI (10K Thermistor)	J20–1, 2
Supply Air Temperature	sat	AI (10K Thermistor)	J2–1, 2
Local Outside Air Temperature Sensor	oatsens	AI (10K Thermistor)	J2–3, 4
Space Temperature Offset Pot	sptopot	AI (100K Potentiometer)	J20–3
Indoor Air Quality	iaq	AI (4–20 ma)	J4–2, 3
Outdoor Air Quality	oaq	AI (4–20 ma)	J4–5, 6
Safety Chain Feedback	safety	DI (24 VAC)	J1–9
Compressor Safety	compstat	DI (24 VAC)	J1–2
Fire Shutdown	firedown	DI (24 VAC)	J1–10
Enthalpy Switch	enthalpy	DI (24 VAC)	J2–6, 7
Humidistat Input Status	humstat	DI (24 VAC)	J5–7, 8
CONFIGURABLE INPUTS*			
Space Relative Humidity	sprh	AI (4–20 ma)	J4–2,3 or J4–5,6
Outside Air Relative Humidity	oarh	AI (4–20 ma)	
Supply Fan Status	fanstat	DI (24 VAC)	J5–1,2 or J5–3,4 or J5 5,6 or J5–7,8
Filter Status	filtstat	DI (24 VAC)	
Remote Occupancy Input	remocc	DI (24 VAC)	
OUTPUTS			
Economizer Commanded Position	econocmd	4–20ma	J2–5
Supply Fan Relay State	sf	DO Relay (24VAC , 1A)	J1–4
Compressor 1 Relay State	comp_1	DO Relay (24VAC , 1A)	J1–8
Compressor 2 Relay State	comp_2	DO Relay (24VAC , 1A)	J1–7
Heat Stage 1 Relay State	heat_1	DO Relay (24VAC , 1A)	J1–6
Heat Stage 2 Relay State	heat_2	DO Relay (24VAC , 1A)	J1–5
Power Exhaust Relay State	aux_2	DO Relay (24VAC , 1A)	J11–3
Dehumidification Relay State	humizer	DO Relay (24VAC, 1A)	J11–7, 8

LEGEND

AI – Analog Input
AO – Analog Output
DI – Discrete Input
DO – Discrete Output

* These inputs (if installed) take the place of the default input on the specific channel according to schematic.
 Parallel pins J5–1 = J2–6, J5–3 = J1–10, J5–5 = J1–2 are used for field–installation.

The RTU-MP controller requires the use of a Carrier space sensor. A standard thermostat cannot be used with the RTU-MP system.

Supply Air Temperature (SAT) Sensor - On FIOP-equipped 50TCQD unit, the unit is supplied with a supply-air temperature (SAT) sensor (33ZCSENSAT). This sensor is a tubular probe type, approx 6-inches (12.7 mm) in length. It is a nominal 10-k ohm thermistor.

The SAT is factory-wired. The SAT probe is wire-tied to the supply-air opening (on the horizontal opening end) in its shipping position. Remove the sensor for installation. Re-position the sensor in the flange of the supply-air opening or in the supply air duct (as required by local codes). Drill or punch a 1/2-in. hole in the flange or duct. Use two field-supplied, self-drilling screws to secure the sensor probe in a horizontal orientation. See Fig. 28.

Outdoor Air Temperature (OAT) Sensor - The OAT is factory-mounted in the EconoMiSer2 (FIOP or

accessory). It is a nominal 10k ohm thermistor attached to an eyelet mounting ring.

EconoMiSer2 - The RTU-MP control is used with EconoMiSer2 (option or accessory) for outdoor air management. The damper position is controlled directly by the RTU-MP control; EconoMiSer2 has no internal logic device.

Outdoor air management functions can be enhanced with field-installation of these accessory control devices:

- Enthalpy control (outdoor air or differential sensors)
- Space CO₂ sensor
- Outdoor air CO₂ sensor

Field Connections - Field connections for accessory sensors and input devices are made the RTU-MP, at plugs J1, J2, J4, J5, J11 and J20. All field control wiring that connects to the RTU-MP must be routed through the raceway built into the corner post as shown in Fig. 22.

The raceway provides the UL required clearance between high- and low-voltage wiring. Pass the control wires through the hole provided in the corner post, then feed the wires thorough the raceway to the RTU-MP. Connect to the wires to the removable Phoenix connectors and then reconnect the connectors to the board.


Space Temperature (SPT) Sensors

A field-supplied Carrier space temperature sensor is required with the RTU-MP to monitor space temperature. There are 3 sensors available for this application:

- 33ZCT55SPT, space temperature sensor with override button
- 33ZCT56SPT, space temperature sensor with override button and setpoint adjustment
- 33ZCT59SPT, space temperature sensor with LCD (liquid crystal display) screen, override button, and setpoint adjustment

Use 20 gauge wire to connect the sensor to the controller. The wire is suitable for distances of up to 500 ft. Use a three-conductor shielded cable for the sensor and setpoint adjustment connections. If the setpoint adjustment (slidebar) is not required, then an unshielded, 18 or 20 gauge, two-conductor, twisted pair cable may be used.


Connect T-55 - See Fig. 30 for typical T-55 internal connections. Connect the T-55 SEN terminals to RTU-MP J20-1 and J20-2. See Fig. 49.



C08460

Fig. 49 - RTU-MP T-55 Sensor Connections


Connect T-56 - See Fig. 32 for T-56 internal connections. Install a jumper between SEN and SET terminals as illustrated. Connect T-56 terminals to RTU-MP J20-1, J20-2 and J20-3 per Fig. 50.



C08461

Fig. 50 - RTU-MP T-56 Sensor Connections

Connect T-59 - The T-59 space sensor requires a separate, isolated power supply of 24 VAC. See Fig. 51 for internal connections at the T-59. Connect the SEN terminal (BLU) to RTU-MP J20-1. Connect the COM terminal (BRN) to J20-2. Connect the SET terminal (STO or BLK) to J20-3.



NOTE: Must use a separate isolated transformer.

C07132

Fig. 51 - Space Temperature Sensor Typical Wiring (33ZCT59SPT)

Economizer controls —

Outdoor Air Enthalpy Control (PNO 33CSENTHSW) -

The enthalpy control (33CSENTHSW) is available as a field-installed accessory to be used with the EconoMi\$er2 damper system. The outdoor air enthalpy sensor is part of the enthalpy control. (The separate field-installed accessory return air enthalpy sensor (33CSENSEN) is required for differential enthalpy control. See Fig. 35.)

Locate the enthalpy control in the economizer next to the Actuator Motor. Locate two GRA leads in the factory harness and connect the gray lead labeled “ESL” to the terminal labeled “LOW”. See Fig. 35. Connect the enthalpy control power input terminals to economizer actuator power leads RED (connect to 24V) and BLK (connect to GND).

The outdoor enthalpy changeover setpoint is set at the enthalpy controller.

Differential Enthalpy Control — Differential enthalpy control is provided by sensing and comparing the outside air and return air enthalpy conditions. Install the outdoor air enthalpy control as described above. Add and install a return air enthalpy sensor.

To wire the return air enthalpy sensor, perform the following:

1. Use a 2-conductor, 18 or 20 AWG, twisted pair cable to connect the return air enthalpy sensor to the enthalpy controller.
2. Connect the field-supplied RED wire to (+) spade connector on the return air enthalpy sensor and the (+) terminal on the enthalpy controller. Connect the BLK wire to (-) spade connector on the return air enthalpy sensor and the (-) terminal on the enthalpy controller.

Indoor Air Quality (CO₂ sensor) — The indoor air quality sensor accessory monitors space carbon dioxide (CO₂) levels. This information is used to monitor IAQ levels. Several types of sensors are available, for wall mounting

in the space or in return duct, with and without LCD display, and in combination with space temperature sensors. Sensors use infrared technology to measure the levels of CO₂ present in the space air.

The CO₂ sensors are all factory set for a range of 0 to 2000 ppm and a linear mA output of 4 to 20. Refer to the instructions supplied with the CO₂ sensor for electrical requirements and terminal locations. See Fig. 37 for typical CO₂ sensor wiring schematic.

To accurately monitor the quality of the air in the conditioned air space, locate the sensor near a return-air grille (if present) so it senses the concentration of CO₂ leaving the space. The sensor should be mounted in a location to avoid direct breath contact.


Do not mount the IAQ sensor in drafty areas such as near supply ducts, open windows, fans, or over heat sources. Allow at least 3 ft (0.9 m) between the sensor and any corner. Avoid mounting the sensor where it is influenced by the supply air; the sensor gives inaccurate readings if the supply air is blown directly onto the sensor or if the supply air does not have a chance to mix with the room air before it is drawn into the return airstream.

Wiring the Indoor Air Quality Sensor —

For each sensor, use two 2-conductor 18 AWG (American Wire Gage) twisted-pair cables (unshielded) to connect the separate isolated 24 vac power source to the sensor and to connect the sensor to the RTU-MP control board terminals.

To connect the sensor to the control, identify the positive (4 to 20 mA) and ground (SIG COM) terminals on the sensor. See Fig. 37. Connect the 4-20 mA terminal to RTU-MP J4-2 and connect the SIG COM terminal to RTU-MP J4-3. See Fig. 52.

IAQ Sensor



C08462


Fig. 52 - RTU-MP / Indoor CO₂ Sensor (33ZCSENCO2) Connections

Outdoor Air Quality Sensor (PNO 33ZCSENCO2 plus weatherproof enclosure) — The outdoor air CO₂ sensor is designed to monitor carbon dioxide (CO₂) levels in the outside ventilation air and interface with the ventilation damper in an HVAC system. The OAQ sensor is packaged with an outdoor cover. See Fig. 39. The outdoor air CO₂ sensor must be located in the economizer outside air hood.

Wiring the Outdoor Air CO₂ Sensor — A dedicated power supply is required for this sensor. A two-wire cable is required to wire the dedicated power supply for the sensor. The two wires should be connected to the power supply and terminals 1 and 2.

To connect the sensor to the control, identify the positive (4 to 20 mA) and ground (SIG COM) terminals on the OAQ sensor. See Fig. 37. Connect the 4 to 20 mA terminal to RTU-MP J4-5. Connect the SIG COM terminal to RTU-MP J4-6.

OAQ Sensor/RH Sensor



C08463

Fig. 53 - RTU-MP / Outdoor CO₂ Sensor (33ZCSENCO2) Connections

On 50TCQD units equipped with factory-installed Smoke Detector(s), the smoke detector controller implements the unit shutdown through its NC contact set connected to the unit's CTB input. The FSD function is initiated via the smoke detector's Alarm NO contact set. The RTU-MP controller communicates the smoke detector's tripped status to the BAS building control. See Fig. 48, the RTU-MP System Control Wiring diagram.

The Fire Shutdown Switch configuration, **MENU→Config→Inputs→input 5**, identifies the normally open status of this input when there is no fire alarm.

Connecting Discrete Inputs

Filter Status

The filter status accessory is a field-installed accessory. This accessory detects plugged filters. When installing this accessory, the unit must be configured for filter status by setting **MENU→Config→Inputs→input 3, 5, 8, or 9** to Filter Status and normally open (N/O) or normally closed (N/C). Input 8 or 9 is recommended for easy of installation. Refer to Fig. 46 and Fig. 48 for wire terminations at J5.

Fan Status

The fan status accessory is a field-installed accessory. This accessory detects when the indoor fan is blowing air. When installing this accessory, the unit must be configured for fan status by setting **MENU→Config→Inputs→input 3, 5, 8, or 9** to Fan Status and normally open (N/O) or normally closed (N/C). Input 8 or 9 is recommended for easy of installation. Refer to Fig. 46 and Fig. 48 for wire terminations at J5.

Remote Occupancy


The remote occupancy accessory is a field-installed accessory. This accessory overrides the unoccupied mode and puts the unit in occupied mode. When installing this accessory, the unit must be configured for remote occupancy by setting *MENU→Config→Inputs→input 3, 5, 8, or 9* to Remote Occupancy and normally open (N/O) or normally closed (N/C).

Also set *MENU→Schedules→occupancy source* to DI on/off. Input 8 or 9 is recommended for easy of installation. Refer to Fig. 46 and Table 8 for wire terminations at J5.

Power Exhaust (output)

Connect the accessory Power Exhaust contactor coil(s) per Fig. 54.

Power Exhaust



C08464

Fig. 54 - RTU-MP Power Exhaust Connections

Space Relative Humidity Sensor - The RH sensor is not used with 50TCQD models at this time.

Communication Wiring - Protocols

General

Protocols are the communication languages spoken by control devices. The main purpose of a protocol is to communicate information in the most efficient method possible. Different protocols exist to provide different kinds of information for different applications. In the BAS application, many different protocols are used, depending on manufacturer. Protocols do not change the function of a controller; just make the front end user different.

The RTU-MP can be set to communicate on four different protocols: BACnet, Modbus, N2, and LonWorks. Switch 3 (SW3) on the board is used to set protocol and baud rate. Switches 1 and 2 (SW1 and SW2) are used to set the board's network address. See Fig 55 for the switch setting per protocol. The 3rd party connection to the RTU-MP is through plug J19.

NOTE: Power must be cycled after changing the SW1-3 switch settings.

Refer to the *RTU-MP 3rd Party Integration Guide* for more detailed information on protocols, 3rd party wiring, and networking.

50TCQD


SW3 Protocol Selection

PROTOCOL	DS8	DS7	DS6	DS5	DS4	DS3	DS2	DS1
BACnet MS/TP (Master)	Unused	OFF	OFF	OFF	ON	OFF	Select Baud	Select Baud
Modbus (Slave)	Unused	OFF	OFF	ON	ON	OFF	Select Baud	Select Baud
N2 (Slave)	Unused	OFF	OFF	OFF	ON	ON	OFF	OFF
LonWorks	Unused	ON	ON	OFF	ON	OFF	OFF	OFF

NOTE:
DS = Dip Switch
BACnet MS/TP SW3 example shown

Baud Rate Selections

BAUD RATE	DS2	DS1
9600	OFF	OFF
19,200	ON	OFF
38,400	OFF	ON
76,800	ON	ON



C07166

Fig. 55 - RTU-MP SW3 Dip Switch Settings

Local Access

BACview⁶ Handheld

The BACview⁶ is a keypad/display interface used to connect to the RTU-MP to access the control information, read sensor values, and test the RTU, see Fig. 56. This is an accessory interface that does not come with the MP controller and can only be used at the unit. Connect the BACview⁶ to the RTU-MP's J12 local access port. There are 2 password protected levels in the display (User and Admin). The user password is defaulted to 0000 but can be changed. The Admin password is 1111 and cannot be changed. There is a 10 minute auto logout if a screen is idle. See Form 48-50H-T-2T, Appendix A for navigation and screen content.

Virtual BACview

Virtual BACview is a freeware computer program that functions as the BACview⁶ Handheld. The USB Link interface (USB-L) is required to connect a computer to the RTU-MP board. The link cable connects a USB port to the J12 local access port. This program functions and operates identical to the handheld.

NOTE: Refer to Form 48-50H-T-2T for complete configuration of RTU-MP, operating sequences and troubleshooting information. Refer to *RTU-MP 3rd Party Integration Guide* for details on configuration and troubleshooting of connected networks. Have a copy of these manuals available at unit start-up.




Fig. 56 - BACview⁶ Handheld Connections

C07170

Smoke Detectors

Smoke detectors are available as factory-installed options on 50TCQD models. Smoke detectors may be specified for Supply Air only or for Return Air without or with economizer or in combination of Supply Air and Return Air. Return Air smoke detectors are arranged for vertical return configurations only. All components necessary for operation are factory-provided and mounted. The unit is factory-configured for immediate smoke detector shutdown operation; additional wiring or modifications to unit terminal board may be necessary to complete the unit and smoke detector configuration to meet project requirements.

System

The smoke detector system consists of a four-wire controller and one or two sensors. Its primary function is to shut down the rooftop unit in order to prevent smoke from circulating throughout the building. It is not to be used as a life saving device.

Controller

The controller (see Fig. 57) includes a controller housing, a printed circuit board, and a clear plastic cover. The controller can be connected to one or two compatible duct smoke sensors. The clear plastic cover is secured to the housing with a single captive screw for easy access to the wiring terminals. The controller has three LEDs (for Power, Trouble and Alarm) and a manual test/reset button (on the cover face).

Sensor

The sensor (see Fig. 58) includes a plastic housing, a printed circuit board, a clear plastic cover, a sampling tube inlet and an exhaust tube. The sampling tube (when used) and exhaust tube are attached during installation. The sampling tube is shipped in the blower section and is wire tied to the blower housing. The clear plastic cover permits visual inspections without having to disassemble the sensor. The cover attaches to the sensor housing using four captive screws and forms an airtight chamber around the sensing electronics. Each sensor includes a harness with an RJ45 terminal for connecting to the controller. Each sensor has four LEDs (for Power, Trouble, Alarm and Dirty) and a manual test/reset button (on the left-side of the housing).

Air is introduced to the duct smoke detector sensor's sensing chamber through a sampling tube that extends into the HVAC duct and is directed back into the ventilation system through a (shorter) exhaust tube. The difference in air pressure between the two tubes pulls the sampled air through the sensing chamber. When a sufficient amount of smoke is detected in the sensing chamber, the sensor signals an alarm state and the controller automatically takes the appropriate action to shut down fans and blowers, change over air handling systems, notify the fire alarm control panel, etc.




Fig. 57 - Controller Assembly

C08208




Fig. 58 - Smoke Detector Sensor


C09070

The sensor uses a process called differential sensing to prevent gradual environmental changes from triggering false alarms. A rapid change in environmental conditions, such as smoke from a fire, causes the sensor to signal an alarm state but dust and debris accumulated over time does not.

For installations using two sensors, the duct smoke detector does not differentiate which sensor signals an alarm or trouble condition.

Smoke Detector Locations

Supply Air — The Supply Air smoke detector sensor is located to the left of the unit's indoor (supply) fan. See Fig. 59. Access is through the fan access panel. There is no sampling tube used at this location. The sampling tube inlet extends through the side plate of the fan housing (into a high pressure area).



C09102


Fig. 59 - Typical Supply Air Smoke Detector Sensor Location

Return Air without Economizer — The return air sampling tube is located across the vertical return air opening across the face of the coil. See Fig. 60. Install the return air sampling tube so that the holes in the tube face downward, into the return air stream for vertical airflow configuration and horizontally facing away from filters for horizontal airflow. The sampling tube snaps into the sensor which protrudes through the back of the control box.

Return Air with Economizer — The sampling tube is inserted into the sensor which protrudes through the back of the control box, placing it across the return air opening on the unit basepan. See Fig. 60. The holes in the sampling tube face downward, into the return air stream for vertical air flow and horizontally facing away from the dampers for horizontal air flow.


Completing Installation of Return Air Smoke Sensor:

1. Locate the magnet; it is shipped in the control box area.
2. To complete the installation, make sure that the exhaust is down stream of the sampling tube as shown in Figs. 60 and 61.



C09135

Fig. 60 - Return Air Sampling Tube Location in Unit without Economizer



C09136

Fig. 61 - Return Air Sampling Tube Location in Unit with Economizer

Additional Application Data — Refer to Catalog No. HKRNKA-1XA for discussions on additional control features of these smoke detectors including multiple unit coordination.

Table 9 – Unit Wire/Fuse or HACR Breaker Sizing Data

UNIT	NOM. V – Ph – Hz	IFM TYPE	ELEC. HTR			PE	NO C.O. or UNPWR C.O.							
			CRHEATER ***A00	Nom (kW)	FLA	FLA	NO PE.				w/ PE. (pwrdr fr/unit)			
							MCA	FUSE or HACR BRKR	DISC. SIZE		MCA	FUSE or HACR BRKR	DISC. SIZE	
									FLA	LRA			FLA	LRA
50TCQ*17	208/230 – 3 – 60	STD	NONE	–	–	5.9	68.3	90.0	71	393	80.1	100.0	85	413
			279A00	18.8/25.0	52.1/60.1		133.4/143.4	150/150	131/140	445/453	145.2/155.2	150/175	145/154	465/473
			280A00	37.6/50.0	104.2/120.3		198.5/188.6	200/200	191/210	497/513	210.3/200.4	225/225	205/223	517/533
			281A00	56.3/75.0	156.4/180.4		224.7/248.7	250/300	251/279	549/573	236.5/260.5	250/300	265/292	569/593
		MED	NONE	–	–	5.9	71.0	90.0	74	410	82.8	100.0	88	430
			279A00	18.8/25.0	52.1/60.1		136.1/146.1	150/150	134/144	462/470	147.9/157.9	150/175	148/157	482/490
			280A00	37.6/50.0	104.2/120.3		201.2/191.3	225/200	194/213	514/530	213.0/203.1	225/225	208/226	534/550
			281A00	56.3/75.0	156.4/180.4		227.4/251.4	250/300	254/282	566/590	239.2/263.2	250/300	268/295	586/610
		HIGH	NONE	–	–	5.9	75.8	100.0	80	419	87.6	100.0	93	439
			279A00	18.8/25.0	52.1/60.1		140.9/150.9	150/175	140/149	471/479	152.7/162.7	175/175	153/163	491/499
			280A00	37.6/50.0	104.2/120.3		206.0/196.1	225/225	200/218	523/539	217.8/207.9	225/225	213/232	543/559
			281A00	56.3/75.0	156.4/180.4		232.2/256.2	250/300	260/287	575/599	244.0/268.0	300/300	273/301	595/619
	460 – 3 – 60	STD	NONE	–	–	3.1	33.6	45.0	35	234	39.8	50.0	42	246
			282A00	25.0	30.1		71.2	80.0	70	264	77.4	80.0	77	276
			283A00	50.0	60.1		93.7	100.0	104	294	99.9	110.0	111	306
			284A00	75.0	90.2		123.8	150	139	324	130.0	150	146	336
		MED	NONE	–	–	3.1	35.0	45.0	37	243	41.2	50.0	44	255
			282A00	25.0	30.1		72.6	80.0	71	273	78.8	80.0	78	285
			283A00	50.0	60.1		95.1	100.0	106	303	101.3	110.0	113	315
			284A00	75.0	90.2		125.2	150	140	333	131.4	150	148	345
		HIGH	NONE	–	–	3.1	37.6	45.0	40	247	43.8	50.0	47	259
			282A00	25.0	30.1		75.2	80.0	74	277	81.4	90.0	81	289
			283A00	50.0	60.1		97.7	110.0	109	307	103.9	110.0	116	319
			284A00	75.0	90.2		127.8	150	143	337	134.0	150	151	349
	575 – 3 – 60	STD	NONE	–	–	2.4	24.9	30.0	26	184	29.7	35.0	32	192
			285A00	24.8	23.9		54.7	60.0	53	208	59.5	60.0	59	216
			286A00	49.6	47.7		84.5	90.0	81	232	89.3	90.0	86	240
			287A00	74.4	71.6		96.5	100	108	256	101.3	110	114	264
		MED	NONE	–	–	2.4	24.9	30.0	26	184	29.7	35.0	32	192
			285A00	24.8	23.9		54.7	60.0	53	208	59.5	60.0	59	216
			286A00	49.6	47.7		84.5	90.0	81	232	89.3	90.0	86	240
			287A00	74.4	71.6		96.5	100	108	256	101.3	110	114	264
		HIGH	NONE	–	–	2.4	27.7	30.0	29	198	32.5	40.0	35	206
			285A00	24.8	23.9		57.5	60.0	57	222	62.3	70.0	62	230
			286A00	49.6	47.7		87.3	90.0	84	246	92.1	100.0	90	254
			287A00	74.4	71.6		99.3	110	112	270	104.1	110	117	278

50TCQD

NOTE: See page 41 for table legend and notes

Table 9 — Unit Wire/Fuse or HACR Breaker Sizing Data (cont)

UNIT	NOM. V – Ph – Hz	IFM TYPE	ELEC. HTR			PE	w/ PWRD C.O.								
			CRHEATER ***A00	Nom (kW)	FLA		FLA	NO PE.				w/ PE. (pwrd fr/unit)			
								MCA	FUSE or HACR BRKR	DISC. SIZE		MCA	FUSE or HACR BRKR	DISC. SIZE	
										FLA	LRA			FLA	LRA
50TCQ*17	208/230 – 3 – 60	STD	NONE	–	–	5.9	73.1	90.0	77	398	84.9	100.0	90	418	
			279A00	18.8/25.0	52.1/60.1		138.2/148.2	150/150	137/146	450/458	150.0/160.0	150/175	150/160	470/478	
			280A00	37.6/50.0	104.2/120.3		203.3/193.4	225/200	197/215	502/518	215.1/205.2	225/225	210/229	522/538	
			281A00	56.3/75.0	156.4/180.4		229.5/253.5	250/300	257/284	554/578	241.3/265.3	250/300	270/298	574/598	
		MED	NONE	–	–	5.9	75.8	100.0	80	415	87.6	100.0	93	435	
			279A00	18.8/25.0	52.1/60.1		140.9/150.9	150/175	140/149	467/475	152.7/162.7	175/175	153/163	487/495	
			280A00	37.6/50.0	104.2/120.3		206.0/196.1	225/225	200/218	519/535	217.8/207.9	225/225	213/232	539/555	
			281A00	56.3/75.0	156.4/180.4		232.2/256.2	250/300	260/287	571/595	244.0/268.0	300/300	273/301	591/615	
		HIGH	NONE	–	–	5.9	80.6	100.0	85	424	92.4	100.0	99	444	
			279A00	18.8/25.0	52.1/60.1		145.7/155.7	150/175	145/155	476/484	157.5/167.5	175/175	159/168	496/504	
			280A00	37.6/50.0	104.2/120.3		210.8/200.9	225/225	205/224	528/544	222.6/212.7	225/225	219/237	548/564	
			281A00	56.3/75.0	156.4/180.4		237.0/261.0	250/300	265/293	580/604	248.8/272.8	300/300	279/306	600/624	
	460 – 3 – 60	STD	NONE	–	–	3.1	35.8	45.0	38	236	42.0	50.0	45	248	
			282A00	25.0	30.1		73.4	80.0	72	266	79.6	80.0	79	278	
			283A00	50.0	60.1		95.9	100.0	107	296	102.1	110.0	114	308	
			284A00	75.0	90.2		126.0	150	141	326	132.2	150	148	338	
		MED	NONE	–	–	3.1	37.2	45.0	39	245	43.4	50.0	46	257	
			282A00	25.0	30.1		74.8	80.0	74	275	81.0	90.0	81	287	
			283A00	50.0	60.1		97.3	110.0	108	305	103.5	110.0	115	317	
			284A00	75.0	90.2		127.4	150	143	335	133.6	150	150	347	
		HIGH	NONE	–	–	3.1	39.8	50.0	42	249	46.0	50.0	49	261	
			282A00	25.0	30.1		77.4	80.0	77	279	83.6	90.0	84	291	
			283A00	50.0	60.1		99.9	110.0	111	309	106.1	110.0	118	321	
			284A00	75.0	90.2		130.0	150	146	339	136.2	150	153	351	
	575 – 3 – 60	STD	NONE	–	–	2.4	26.6	30.0	28	186	31.4	40.0	33	194	
			285A00	24.8	23.9		56.4	60.0	55	210	61.2	70.0	61	218	
			286A00	49.6	47.7		86.2	90.0	83	234	91.0	100.0	88	242	
			287A00	74.4	71.6		98.2	110	110	258	103.0	110	116	266	
		MED	NONE	–	–	2.4	26.6	30.0	28	186	31.4	40.0	33	194	
			285A00	24.8	23.9		56.4	60.0	55	210	61.2	70.0	61	218	
			286A00	49.6	47.7		86.2	90.0	83	234	91.0	100.0	88	242	
			287A00	74.4	71.6		98.2	110	110	258	103.0	110	116	266	
		HIGH	NONE	–	–	2.4	29.4	35.0	31	200	34.2	40.0	37	208	
			285A00	24.8	23.9		59.2	60.0	59	224	64.0	70.0	64	232	
			286A00	49.6	47.7		89.0	90.0	86	248	93.8	100.0	92	256	
			287A00	74.4	71.6		101.0	110	114	272	105.8	110	119	280	

NOTE: See page 41 for table legend and notes

Table 9 — Unit Wire/Fuse or HACR Breaker Sizing Data (cont)

UNIT	NOM. V—Ph—Hz	IFM TYPE	ELEC. HTR			PE	NO C.O. or UNPWR C.O.							
			CRHEATER ***A00	Nom (kW)	FLA	FLA	NO P.E.				w/ P.E. (pwrd fr/unit)			
							MCA	FUSE or HACR BRKR	DISC. SIZE		MCA	FUSE or HACR BRKR	DISC. SIZE	
									FLA	LRA			FLA	LRA
50TCQ*24	208/230—3—60	STD	NONE	—	—	5.9	92.7	125.0	97	558	104.5	125.0	111	578
			279A00	18.8/25.0	52.1/60.1		157.9/167.9	175/175	157/166	610/618	169.7/179.7	175/200	171/180	630/638
			280A00	37.6/50.0	104.2/120.3		223.0/213.0	225/225	217/235	662/678	234.8/224.8	250/250	230/249	682/698
			281A00	56.3/75.0	156.4/180.4		249.1/273.1	300/300	277/305	714/738	260.9/284.9	300/300	290/318	734/758
		MED	NONE	—	—	5.9	98.1	125	103	568	109.9	125	117	588
			279A00	18.8/25.0	52.1/60.1		163.3/173.3	175/175	163/172	620/628	175.1/185.1	200/200	177/186	640/648
			280A00	37.6/50.0	104.2/120.3		228.4/218.4	250/250	223/242	672/688	240.2/230.2	250/250	237/255	692/708
			281A00	56.3/75.0	156.4/180.4		254.5/278.5	300/300	283/311	724/748	266.3/290.3	300/300	297/324	744/768
		HIGH	NONE	—	—	5.9	110.8	125	118	642	122.6	150	131	662
			279A00	18.8/25.0	52.1/60.1		176.0/186.0	200/200	178/187	694/702	187.8/197.8	200/200	191/201	714/722
			280A00	37.6/50.0	104.2/120.3		241.1/231.1	250/250	238/256	746/762	252.9/242.9	300/300	251/270	766/782
			281A00	56.3/75.0	156.4/180.4		267.2/291.2	300/300	298/325	798/822	279.0/303.0	300/350	311/339	818/842
	460—3—60	STD	NONE	—	—	3.1	50.1	60.0	52	288	56.3	70.0	60	300
			282A00	25.0	30.1		87.7	90	87	318	93.9	100	94	330
			283A00	50.0	60.1		110.2	125	122	348	116.4	125	129	360
			284A00	75.0	90.2		140.3	150	156	378	146.5	175	163	390
		MED	NONE	—	—	3.1	52.9	60	56	293	59.1	70	63	305
			282A00	25.0	30.1		90.5	100	90	323	96.7	100	97	335
			283A00	50.0	60.1		113.0	125	125	353	119.2	125	132	365
			284A00	75.0	90.2		143.1	150	159	383	149.3	175	167	395
		HIGH	NONE	—	—	3.1	58.9	70	63	330	65.1	80	70	342
			282A00	25.0	30.1		96.5	100	97	360	102.7	110	104	372
			283A00	50.0	60.1		119.0	125	132	390	125.2	150	139	402
			284A00	75.0	90.2		149.1	175	166	420	155.3	175	173	432
	575—3—60	STD	NONE	—	—	2.4	36.2	45.0	38	204	41.0	50.0	43	212
			285A00	24.8	23.9		66.1	70	65	228	70.9	80	71	236
			286A00	49.6	47.7		95.8	100	93	252	100.6	110	98	260
			287A00	74.4	71.6		107.8	125	120	276	112.6	125	126	284
		MED	NONE	—	—	2.4	39.6	50	42	202	44.4	50	47	210
			285A00	24.8	23.9		69.5	70	69	226	74.3	80	75	234
			286A00	49.6	47.7		99.2	100	97	250	104.0	110	102	258
			287A00	74.4	71.6		111.2	125	124	274	116.0	125	130	282
		HIGH	NONE	—	—	2.4	40.1	50	42	229	44.9	50	48	237
			285A00	24.8	23.9		70.0	70	70	253	74.8	80	75	261
			286A00	49.6	47.7		99.7	100	97	277	104.5	110	103	285
			287A00	74.4	71.6		111.7	125	125	301	116.5	125	130	309

50TCQD

NOTE: See page 41 for table legend and notes

Table 9 — Unit Wire/Fuse or HACR Breaker Sizing Data (cont)

UNIT	NOM. V—Ph—Hz	IFM TYPE	ELEC. HTR			PE	w/ PWRD C.O.								
			CRHEATER ***A00	Nom (kW)	FLA		FLA	NO PE.				w/ P.E. (pwrd fr/unit)			
								MCA	FUSE or HACR BRKR	DISC. SIZE		MCA	FUSE or HACR BRKR	DISC. SIZE	
										FLA	LRA			FLA	LRA
50TCQ*24	208/230—3—60	STD	NONE	—	—	5.9	97.5	125.0	103	563	109.3	125.0	116	583	
			279A00	18.8/25.0	52.1/60.1		162.7/172.7	175/175	162/172	615/623	174.5/184.5	175/200	176/185	635/643	
			280A00	37.6/50.0	104.2/120.3		227.8/217.8	250/250	222/241	667/683	239.6/229.6	250/250	236/254	687/703	
			281A00	56.3/75.0	156.4/180.4		253.9/277.9	300/300	282/310	719/743	265.7/289.7	300/300	296/324	739/763	
		MED	NONE	—	—	5.9	102.9	125.0	109	573	114.7	125.0	122	593	
			279A00	18.8/25.0	52.1/60.1		168.1/178.1	175/200	169/178	625/633	179.9/189.9	200/200	182/191	645/653	
			280A00	37.6/50.0	104.2/120.3		233.2/223.2	250/250	229/247	677/693	245.0/235.0	250/250	242/261	697/713	
			281A00	56.3/75.0	156.4/180.4		259.3/283.3	300/300	289/316	729/753	271.1/295.1	300/350	302/330	749/773	
		HIGH	NONE	—	—	5.9	115.6	125.0	123	647	127.4	150	137	667	
			279A00	18.8/25.0	52.1/60.1		180.8/190.8	200/200	183/193	699/707	192.6/202.6	200/225	197/206	719/727	
			280A00	37.6/50.0	104.2/120.3		245.9/235.9	250/250	243/262	751/767	257.7/247.7	300/300	257/275	771/787	
			281A00	56.3/75.0	156.4/180.4		272.0/296.0	300/350	303/331	803/827	283.8/307.8	300/350	317/344	823/847	
	460—3—60	STD	NONE	—	—	3.1	52.3	60.0	55	290	58.5	70.0	62	302	
			282A00	25.0	30.1		89.9	100.0	90	320	96.1	100.0	97	332	
			283A00	50.0	60.1		112.4	125.0	124	350	118.6	125.0	131	362	
			284A00	75.0	90.2		142.5	150	159	380	148.7	175	166	392	
		MED	NONE	—	—	3.1	55.1	60.0	58	295	61.3	70.0	65	307	
			282A00	25.0	30.1		92.7	100.0	93	325	98.9	100.0	100	337	
			283A00	50.0	60.1		115.2	125.0	127	355	121.4	150.0	134	367	
			284A00	75.0	90.2		145.3	150	162	385	151.5	175	169	397	
		HIGH	NONE	—	—	3.1	61.1	70.0	65	332	67.3	80	72	344	
			282A00	25.0	30.1		98.7	100.0	100	362	104.9	110.0	107	374	
			283A00	50.0	60.1		121.2	150.0	134	392	127.4	150.0	141	404	
			284A00	75.0	90.2		151.3	175	169	422	157.5	175	176	434	
	575—3—60	STD	NONE	—	—	2.4	37.9	50.0	40	206	42.7	50.0	45	214	
			285A00	24.8	23.9		67.8	70.0	67	230	72.6	80.0	73	238	
			286A00	49.6	47.7		97.5	100.0	95	254	102.3	110.0	100	262	
			287A00	74.4	71.6		109.5	125	122	278	114.3	125	128	286	
		MED	NONE	—	—	2.4	41.3	50.0	44	204	46.1	50.0	49	212	
			285A00	24.8	23.9		71.2	80.0	71	228	76.0	80.0	77	236	
			286A00	49.6	47.7		100.9	110.0	99	252	105.7	110.0	104	260	
			287A00	74.4	71.6		112.9	125	126	276	117.7	125	132	284	
		HIGH	NONE	—	—	2.4	41.8	50.0	44	231	46.6	50	50	239	
			285A00	24.8	23.9		71.7	80.0	72	255	76.5	80.0	77	263	
			286A00	49.6	47.7		101.4	110.0	99	279	106.2	110.0	105	287	
			287A00	74.4	71.6		113.4	125	127	303	118.2	125	132	311	

NOTE: See page 41 for table legend and notes

Legend and Notes for Table 9

LEGEND:

- BRKR – Circuit breaker
- CO – Convenient outlet
- DD – Direct drive indoor fan motor
- DISC – Disconnect
- FLA – Full load amps
- IFM – Indoor fan motor
- LRA – Locked rotor amps
- MCA – Minimum circuit amps
- PE – Power exhaust
- PWRD CO – Powered convenient outlet
- UNPWR CO – Unpowered convenient outlet



NOTES:

1. In compliance with NEC requirements for multimotor and combination load equipment (refer to NEC Articles 430 and 440), the overcurrent protective device for the unit shall be fuse or HACR breaker. Canadian units may be fuse or circuit breaker.
2. **Unbalanced 3-Phase Supply Voltage**
Never operate a motor where a phase imbalance in supply voltage is greater than 2%. Use the following formula to determine the percentage of voltage imbalance.

% Voltage Imbalance = 100 x $\frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$

Example: Supply voltage is 230-3-60



- AB = 224 v
- BC = 231 v
- AC = 226 v

Average Voltage = $\frac{(224 + 231 + 226)}{3} = \frac{681}{3}$

= 227

Determine maximum deviation from average voltage.

(AB) 227 – 224 = 3 v

(BC) 231 – 227 = 4 v

(AC) 227 – 226 = 1 v

Maximum deviation is 4 v.

Determine percent of voltage imbalance.

% Voltage Imbalance = 100 x $\frac{4}{227}$

= 1.76%

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

IMPORTANT: If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

50TCQD




Fig. 62 - EconoMi\$er™ IV Wiring

C10183

Step 11 — Adjust Factory-Installed Options**Smoke Detectors —**

Smoke detector(s) will be connected at the Controls Connections Board, at terminals marked “Smoke Shutdown”. Remove jumper JMP 3 when ready to energize unit.

EconoMi\$er IV Occupancy Switch —

Refer to Fig. 62 for general EconoMi\$er IV wiring. External occupancy control is managed through a connection on the Central Terminal Board.

If external occupancy control is desired, connect a time clock or remotely controlled switch (closed for Occupied, open for Unoccupied sequence) at terminals marked OCCUPANCY on CTB. Remove or cut jumper JMP 2 to complete the installation.

Step 12 — Install Accessories

Available accessories include:

- Roof Curb
- Thru-base connection kit (must be installed before unit is set on curb)
- Manual outside air damper
- Two-Position motorized outside air damper

EconoMi\$er IV (with control and integrated barometric relief)

EconoMi\$er2 (without control/for external signal and integrated barometric relief)

Power Exhaust

Differential dry-bulb sensor (EconoMi\$er IV)

Outdoor enthalpy sensor

Differential enthalpy sensor

Electric Heaters

Single Point kits

Low Ambient Controls

Thermostat / Sensors

CO₂ sensor

DDC interface (PremierLink)

Louvered hail guard

Phase monitor control

Winter Start kit

Refer to separate installation instructions for information on installing these accessories.

Pre-Start and Start-Up

This completes the mechanical installation of the unit. Refer to the unit's Service Manual for detailed Pre-Start and Start-up instructions.

APPENDIX — TYPICAL WIRING DIAGRAMS




Fig. 63 - 50TCQ Typical Unit Wiring Diagram - HP Control 460V, 575V 3 Phase




Fig. 64 - 50TCQ Typical Unit Wiring Diagram - Power 460V, 575V 3 Phase

C10186